

**Product Code:** CSP031

**Description:** Smart Window & Door Sensor



**General Information**

<b>Magnet Dimensions (mm)</b>	26 (L) x 10 (W) x 9 (D)	
<b>Transmitter Dimensions (mm)</b>	40 (L) x 25 (W) x 14.5 (D)	
<b>Finish</b>	White	
<b>Materials</b>	Housing: Polycarbonate	Electronics: PCB & Electronic Components
<b>Rated Voltage (DC)</b>	3	
<b>Battery Type</b>	CR 2032 (Supplied)	
<b>Battery Lifetime (Approx.)</b>	1 Year (Dependent On Use)	
<b>Protocol</b>	Zigbee	<b>Signal Transmission Frequency</b> 2.4GHz
<b>Activation Distance (mm)</b>	10 - 20 (Between Sensor & Magnet)	
<b>Indicator Colour</b>	Blue	
<b>Ingress Protection</b>	IP20	
<b>Working Humidity</b>	0%-95%RH (Non-condensing)	
<b>Operational Temperature (°C)</b>	-10 to +50	
<b>Warranty (Years)</b>	1	

**Additional Information** For cleaning / polishing of products, use only a soft, dry, clean cloth.  
Control linked receivers through the ClickSmart+ app  
Send activation alerts to your phone

**Components Supplied** Smart Window & Door Sensor Reset Key Instruction Manual

**Installation Overview** Suitable for doors or windows.  
Self-adhesive pads applied ready for installation.

**Programming Information** With hub and app setup with sensor having battery installed, using the pin supplied press the reset button for five seconds and the sensor LED will start flashing. Can be paired with hub via app.