




QUALITY SPACE HEATERS



Installation & Control Guide for Slimline Wall Mounted Fan Heaters with Intelligent Fan Control & Electronic 7-Day Timer

Models

PLSTi050E, PLSTi075E, PLSTi100E, PLSTi150E, PLSTi150SSE

Please note:

'SS' suffix added to model number denotes Stainless Steel derivative.

All electrical appliances produced for the Company are guaranteed for one year against faulty material or workmanship. This applies only if the appliance has been used for purposes in accordance with the instructions provided and has not been connected to an unsuitable electricity supply, or subject to misuse, neglect, damage or modified or repaired by any person not authorised by us. This guarantee is offered to you as an extra benefit and does not affect your legal rights.

The correct electricity supply voltage is shown on the rating label attached to the appliance.

Reasonable care has been taken to ensure that this guide is accurate at the time of printing. In the interest of progress the Company reserve the right to vary specifications from time to time without notice.

General Safety

Our Low Surface Temperature heaters have been designed and built to the NHS requirement for safe surface temperatures which is that no surface which can be touched by the user will be more than 43 °C (at a room temperature of 21 °C) This means that our Low Surface Temperature heaters out-perform the European Standard by a significant margin.

The appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities or lack of experience and knowledge unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

Safety Monitor

As part of the intelligent control (see section 15), the heater has built in safety monitoring. In the unlikely event of a fault, the safety monitoring will help prevent high surface temperatures. The safety monitor will identify overheating, fan failure and certain electronic faults. When the safety monitor identifies a fault, the heat is switched off and the problem is indicated by a buzzer. The heater will beep at different intervals depending on the problem, this enables easy diagnosis.

The faults fall into three categories:

Overheating

A rapid temperature rise (e.g. due to covering the heater) will be detected as a fault and the heat is switched off until the heater is reset at the supply. In the case of an abnormally high temperature, the heat is switched off and will switch back on when the temperature drops.

3 beeps every 15 seconds – Heater overheat

Temperature Sensor Fault

Heater can be used but has limited functionality - the fan runs at maximum speed in order to avoid overheating. It is advisable that the heater is checked by a qualified person.

2 beeps when switching on – Temperature sensor fault

Serious Fault, Heater Should Be Switched Off At Supply

Heater should not be used and should be repaired by a qualified person.

4 beeps every 5 seconds – Power sensor fault

1 beep every second – Motor Fault

1 beep twice a second – Other fault and unable to switch heat off

The heater will continue to indicate a fault has occurred until it is switched off at the supply.

Thermally Operated Cut-Out

The appliance is fitted with a thermally operated cut-out (TOC). In the unlikely event that the safety monitor fails, this safety device will switch the heater off if the appliance overheats. If the TOC has tripped there is a high possibility the heater is faulty and should be checked by a qualified person. The TOC can only re-set after the appliance has cooled down, however we advise not to do this until the heater has been checked

In order to re-set the TOC, proceed as follows:


- Switch off appliance and leave for approximately 10 minutes.
- Switch appliance back on and the TOC will re-set.
- Ensure that the appliance is functioning correctly. If the TOC control operates again, the appliance should be checked by a qualified person.

The heater carries a 'Do Not Cover' label to warn the user that if the appliance is covered, there is a risk of overheating.

Warning

- Do NOT site the appliance into a corner.
- Do NOT handle the appliance with wet hands.
- Do NOT use the appliance in workshops or rooms where excessive dust is generated or present.
- Ensure that nothing is pushed into the air outlet of this appliance.
- Do NOT touch outlet grille when the appliance is in use.
- Do NOT cover or restrict the appliance when in use.
- Do NOT use the appliance if damaged.
- Do NOT leave the appliance unattended where young children are present.
- This appliance must be earthed.

Installation



MILLIMETRES					
	WATTS	A	B	C	D/E
PLSTi050E/PLSTi075E	500/750	506	430	210	148
PLSTi100E	1000	640	430	364	138
PLSTi150E/SSE	1500	892	430	616	138

See Note 16 for Mounting




Fig 1





Fig 2



Fig 3



1. Basic Operation

When the appliance is connected to the mains supply and the wall socket is switched 'ON', the LED indicator on the moulding will light up green, showing that the power is available to the unit. Before you can use the PLSTiE, it has to be activated by pressing any control button. The LCD backlight will turn on. To operate any control button, press within 2 seconds of activation.

2. Time and day setting

-Press and hold the TIME button for 5 seconds.

Minutes are flashing - use TEMP and MODE buttons to set minutes.

-Press TIME button

Hours are flashing - use TEMP and MODE buttons to set hours.

-Press TIME button

Day is flashing - use TEMP and MODE buttons to set Day.

Once you are happy with the settings, press 'Time' to return to main screen.

3. Selecting operating mode

PLSTiE has 4 operating modes:

BOOST, MANUAL, SET BACK, PROGRAM.

Each mode can be selected by pressing the MODE button to cycle through the options. The cycle sequence will always start with BOOST mode followed by MANUAL, SET BACK and PROGRAM.

4. BOOST - 15 minutes

The boost feature increases the room temperature for 15 minutes.

1. Use TEMP and MODE to set the temperature.

To amend the set temperature when in Boost mode, simply activate the display by pressing any button. Press TEMP, then use TEMP and MODE to change the temperature. Once the temperature is set, you can leave the display to return to the main screen and the settings will be saved. After 15 minutes, the PLSTiE will return to previous operating mode.

5. MAN - Manual Mode

In manual mode, the heater maintains the set temperature.

1. Use TEMP and MODE to set the temperature.

To amend the set temperature when in Manual mode, simply activate the display by pressing any button. Press TEMP, then use TEMP and MODE to change the temperature. Once the temperature is set, leave the display to return to the main screen and the settings will be saved.

6. SETB - Reduction in programmed temperature

Setback mode can be used for frost protection, situations where a minimum room temperature must be maintained, or to disable the heating completely.

To amend the set temperature when in Setback mode, simply activate the display by pressing any button. Press TEMP, then use TEMP and MODE to change the temperature. Once the temperature is set, leave the display to return to the main screen and the settings will be saved. When the room temperature drops below the set temperature the heating will be active.

To disable heating lower the temperature to below 4°C and the screen will show '- - -'. The heating is now disabled.


7. PROG - Automatic time mode

In this mode, the PLSTiE will follow the week's time / temperature programme.


You can temporarily override the temperature in **PROG** mode by simply activating the display and using the TEMP and MODE buttons to set the new temperature. The new set temperature will be then maintained until the next program step.

8. Set 7-day programme

An example of one day programme on PLSTIE



Logic diagram for setting programme on PLSTIE



1. Press and hold PROG for 5 seconds to enter the time setting.
2. The day will be flashing.
3. Use TEMP and MODE to navigate day, press PROG to select day.
4. PROG 1 will be flashing. Use TEMP and MODE to navigate programme, use PROG to select programme.
5. The minutes will be flashing.
6. To set minutes, use TEMP and MODE to change minutes, press PROG to set the minutes.
7. The hour will be flashing
8. To set hour, use TEMP and MODE to change hour, press PROG to set the hour.
9. The temperature will be flashing.
10. To set temperature, use TEMP and MODE to change temperature, press PROG to set temperature.

To add another programme repeat steps 2-10.

Copy day function.

If you require the same set of programmes throughout the week it is possible to copy all the programmes from one day to another.

To do this, when in programming mode press and hold the TIME button and this will bring you to the copy day mode. To select which day you wish to copy press the PROG button and this will cycle through numbers 1-7 on the screen, this relates to which day you would like to copy. 1=MON, 2=TUE, 3=WED etc.

To select which day you would like to copy the programmes to, use the TEMP & MODE to navigate to the day. Once both are selected, press the time button to copy the day.

The PLSTIE has a 7-day timer with up to 6 programming steps available for each day. In the programming you can set a start time and a temperature for each programme.

Set programme inactive.

If you do not require the use of all 6 programmes they can be set as inactive. When in programming mode select the programme you want to make inactive and press the TEMP button. If the programme is inactive the display will show "- :- -". To activate the programme again press the TEMP button.


10. Heat symbol on the display

Every time there is a demand for heat, the display will show the heat icon.

⏏ - reduced heat output when the room temperature is close to the set temperature.

⏏⏏⏏ - full heat output

11. Keys locking

Press and hold TIME and TEMP together for 5 seconds. The display will show  symbol. Repeat the step to unlock.

9. Advance mode

Press PROG from PROG mode to bring forward the next programme. To clear advance mode, press PROG.

13. Open Window Detection

Ensuring you don't waste energy on heating the outside world, the heater is equipped with optional open / closed window detection. The heater recognises sudden drops in temperature when a window or a door is opened and turns the heating off to save energy. When the window is closed, the heater will automatically detect a temperature rise, and switch itself back on. Once enabled in the setup menu, the open window detection is fully automatic and does not require any human intervention to be activated.

Setting-up Open Window Detection

The system has been factory set to default time and temperature values. If necessary, all values can be adjusted. When the heating is on, open window detection sensor will automatically switch the heater off when it detects a fall in temperature of 2°C in less than 10 minutes (this temperature can be changed in menu 7 and time in menu 6). If a temperature rise of 2°C in less than 30 seconds is detected, the heater will switch itself back on (this temperature can be changed in menu 9 and time in menu 8).

14. Setup menu

1. Press and hold TEMP and MODE together for 5 seconds.
2. The display will enter the setup menu.
3. Use TEMP and MODE to change a value.
4. Use TIME to scroll between the settings.

01 - temperature calibration

The temperature reading has been factory calibrated but if for any reason it needs adjusting (better accuracy required, to suit different position in the room etc.), the reading can be recalibrated in 0.5 degrees steps.

02 - change between degrees Celsius or Fahrenheit

03 - set minimum temperature (3.5 deg = frost protection)

When this is set, the heater will operate in any mode should the room temperature fall below the set temperature.

04 - set maximum temperature

When this is set, the maximum temperature in any mode cannot exceed the limit.

05 - open window detection 0 = off, 1 = on




06 - 600 - open window detection time 600 seconds

07 - 2 - temperature drop of 2°C in the detection time

08 - 30 - closed window detection time of 30 seconds

09 - 2 - temperature rise of 2°C in the detection time

12. Status light on the heater

Light colour	Heater status
	STAND-BY No heat output
	Reduced heat output
	Full power heat output

15. Intelligent Fan Control

The intelligent fan control incorporates one of the latest low energy consumption BLDC motors. This allows the heater to operate quietly, whilst still providing the best possible levels of comfort.

Depending on which heat mode is activated, it will calculate the best possible airflow temperature and will adjust the fan speed accordingly. If the heater is running in fan mode only (heat switched off), then the fan will operate at a fixed speed.

NOTE: When turning the heater on, there is a 30 seconds delay until the fan starts running to allow the heater to warm up. After the heater is switched OFF the fan will continue running for a short period of time. When changing the heat mode or fan speed mode, the fan will respond accordingly after a small time delay.

16. Mounting

This unit is for wall mounting only. It is designed to be very quiet in operation if mounted correctly. It must be fitted using the wall bracket supplied which has been specially designed to minimise noise levels. **Care must be taken when handling the bracket not to bend or distort it.** When fitting more than one heater into a room we would recommend that they are sited on the same wall to optimise airflow and ensure quiet operation.

MOUNTING ON A PLASTERBOARD WALL

- Ensure at least one of the wall brackets is secured to the timber frame of the studded wall by using standard wood screws.
- Where the bracket is fitted onto plasterboard only, ensure plasterboard fixings are used. Standard wall plugs will not be suitable.
- Where possible mount the heater(s) on an outside wall to inhibit transfer of sound within the building.

NB: Failure to follow the instructions and recommendations provided could result in increased noise levels.

To wall mount, the wall bracket supplied must be used. Remove the wall bracket from the heater, with the chains attached, by removing the 2 securing screws from the top of the rear panel.

Fix the wall bracket to the wall using 4 screws.

Fig 1: Present the heater to the bracket

Fig 2: Locate the heater onto the bottom lugs via the 2 slots in rear panel. Hinge the heater upwards and reattach the chain assembly, then move the heater to the upright position. The link plates should slide under the slotted bracket lip.

Fig 3: Tighten both retaining screws.

The heater must not be located immediately below a fixed socket outlet.

17. Cleaning

Always disconnect the heater from the mains before cleaning. The heater should not require any maintenance, but it is strongly advised that it is kept clean. An occasional wipe over with a soft cloth is all that should be necessary.

- Do NOT use metal or furniture polish on any part of the heater.
- Do NOT touch the heater with wet hands or in any way bring water into contact with it.

If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.

18 . Connection to the Main Supply

Electrical installation should be carried out by a competent installer, preferably registered with NICEIC (National Inspection Council for Electrical Installation Contracting) in accordance with the 17 edition of the IEE Wiring Regulations, (BS.7671), and any relevant Local Authority By-Laws. This heater is fitted with a 3-core mains supply cable and should be permanently connected to the electricity supply via a double pole switch having 3mm gap on each pole.

A switched Fused Connection unit to BS.1363. Part 4 is a recommended mains supply connection accessory to ensure compliance with safety requirements applicable to fixed-wiring installation.

Note: When switched on for the first time the appliance may emit a slight smell. This is purely the evaporation of a fluid used in the manufacturing process.

19. If Your Heater Does Not Work

- Check that power is available to the heater. The neon in the control switch should be illuminated.
- Check that the thermal cut-out has not operated. Follow the reset instructions given under the section headed 'Thermal Operated Cut-out'.
- Check that the fuse in the spur unit has not blown. This can be done by replacing the fuse with another suitable fuse.

Should none of the above remedies work, then telephone the helpline number shown in these instructions (UK ONLY). Do not attempt to repair the heater.

20. Optional PLK1 Locking Device

The PLK1 locking device can be used to mechanically lock the controls to prevent tampering with settings. As it is not supplied with the heater, kindly contact our Sales team if required.



- Locking tab



- Locking screw



Locking tab

Locking screw

CUSTOMER HELPLINE

Should you need any advice on the use of your new Consort product please contact our Helpline:

Consort Equipment Products Limited

Thornton Industrial Estate, Milford Haven, Pembrokeshire, SA73 2RT

Tel: 01646 692172 Fax: 01646 695195 Email: technical@consortepl.com Web: www.consortepl.com

Operation hours: Mon to Thu 8.30am to 4.30pm | Fri 8.30am to 3.30pm

BS EN ISO 9001 Registered Company No FM12671